Users Manual

Multimedia
Surround Sound
Speakers

MM51.6

The lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of un-insulated “dangerous voltage” within the products enclosure that may be of sufficient magnitude to constitute risk of electric shock to persons.

The exclamation point within an equilateral triangle is intended to alert the user to the presence of important safety instructions in the literature accompanying the appliance.

WARNING: TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE.

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
11. Only use attachments/accessories specified by the manufacturer.
12. Unplug this apparatus during lightning storms or when unused for long periods of time.
13. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
14. Maintain a minimum distance of 50 mm around the front, rear and sides of the apparatus for sufficient ventilation. The ventilation should not be impeded by covering the ventilation openings or placing on or around the apparatus items such as newspapers, table-cloths, curtains, etc.
15. No naked flame sources, such as lighted candles, should be placed on the apparatus.
16. The apparatus shall not be exposed to dripping or splashing. No objects filled with liquids, such as vases, shall be placed on the apparatus.
17. Either the power inlet connector on the rear of the apparatus or the power plug at the wall must remain accessible, to be able to disconnect power from the apparatus.
18. To completely disconnect this apparatus from the AC Mains, disconnect the power supply cord plug from the AC receptacle.

Thank you. And congratulations!

Our thanks for buying your new speakers from TSC. We sincerely appreciate your confidence in us and our products.

Please read this Owner's Manual! It contains many tips on getting your new speakers set up, connected, and sounding as good as they should. We hope you find it clear, concise, and helpful.

Again, thank you.

Out Of The Box

You should save the carton and the inserts your speakers came in. You may need to store or ship your TSC speakers in the future and the packaging is designed to protect them from damage.

Where Should You Put Them?

Subwoofer: The MM51.6 subwoofer can go almost anywhere around your computer/multimedia source. The only limitations are:

- The cable length between the subwoofer module and the wired remote controller.
- The Infrared remote controller needs line-of-sight access to the subwoofer module in order to establish the communications link that will let you use the wireless Infrared controller.

Satellite Speakers: These can be placed in any convenient location. The only limitation is the length of the wire that connects them to the subwoofer module. For computer use, the front Left, and Right speakers should flank your video monitor while the Center Channel Speaker should be as close to the monitor as possible. The two Surround speakers should be placed behind and to either side of the user.

Connecting And Using Your tSc MM51.6 Multimedia Speaker System

- Connect the satellite speakers to the appropriate speaker outputs on the rear of the subwoofer module. (Note that you'll be connecting five (5) satellites for surround sound reproduction.)
- Begin with the Left Front speaker
    - Find the red (positive or "+") and black (negative or "-") speaker terminals. .
    - Insert the Left Front speaker wire's positive conductor (usually blue or white) into the recess of the Left Front channel's red terminal by pressing the red tab down, inserting the wire, and then releasing the tab.
    - Insert the Left Front speaker wire's negative conductor (usually black) into the recess of the Left Front channel's black terminal by pressing the black tab down, inserting the wire, and then releasing the tab.
- Repeat these steps for the Center channel using the wire from the satellite you will use as the Center channel speaker. (Note that the Center channel's positive terminal is *blue*.)
- Repeat these steps for the Right Front channel using the wire from the satellite you will use as the Right Front speaker. (Note that the Right Front channel's positive terminal is *red*.)

- Repeat these steps for the Left Surround channel using the wire from the satellite you will use as the Left Surround speaker. (Note that the Left Surround channel's positive terminal is *tan*.)
- Repeat these steps for the Right Surround channel using the wire from the satellite you will use as the Right Surround speaker. (Note that the Right Surround channel's positive terminal is *tan*.)
- Connect a 5.1 channel surround source (DVD player, game console, etc.) to the three (3) 3.5 mm stereo mini-plugs on the subwoofer module's rear panel marked Front Right/Left, Rear Right/Left, and Subwoofer/Center).
- Connect a 2 channel stereo source (computer, portable media player, etc.) to the 3.5 mm stereo mini-plug on the wired remote controller. (Note: You can also connect a two channel source to the Front Right/Left 3.5 mm stereo mini-plug on the subwoofer module. However, this will make that plug unusable for a 5.1 source.)
- If desired, connect headphones to the 3.5 mm stereo mini-plug headphone plug on the wired remote. (Connecting headphones will mute the speakers.)
- Plug the AC cord from the subwoofer module's rear panel into a 110v wall plug.
- Turn your source and the tSc MM51.6 speaker system on.
- Enjoy the sound.

Care

Your TSC speakers don't need much maintenance. Dust them occasionally.

Above all, enjoy! That's what your TSC speakers were designed for and why we take such pride in bringing them to you!

tSc the Speaker company

© 2007 The Speaker Company. All rights reserved.
www.thespeakercompany.com